



**ELECTRIC VEHICLE CHARGER  
EVC12 VESPER SERIES**

User Manual



## CONTENTS

1 - SAFETY INFORMATION .....	2
1.1 - SAFETY WARNINGS .....	2
1.2 - INSTRUCTIONS FOR DEALING WITH A FIRE AT CHARGING STATION .....	3
1.3 - GROUND CONNECTION WARNINGS .....	4
1.4 - POWER CABLES, PLUGS and CHARGING CABLE WARNINGS .....	4
1.5 - PROTECTIONS REQUIRED BEFORE SYSTEM .....	4
2 - DESCRIPTION .....	5
3 - ELECTRICAL SPECIFICATIONS .....	6
4 - USER INTERFACE & AUTHENTICATION .....	6
5 - CONNECTIVITY .....	7
6 - MECHANIC SPECIFICATIONS .....	7
7 - ENVIRONMENTAL TECHNICAL SPECIFICATIONS .....	7
8 - BEHAVIOR OF STATUS INFORMATION LED .....	8
9 - GENERAL INFORMATION .....	9
9.1 - INTRODUCTION OF THE PRODUCT COMPONENTS .....	9
9.2 - CCS OUTLET .....	10
10 - CHARGING SCENARIOS (INCLUDES ALL SCENARIOS) .....	11
10.1 - DC CCS OUTLET .....	11
10.1.1 - VEHICLE CONNECTION & CHARGING .....	11
10.1.2 - STOP CHARGING .....	13
10.1.3 -CHARGING COMPLETED .....	15
10.1.4 - EMERGENCY STOP (OPTIONAL) .....	16
11 - PRODUCTS WITH CERTIFIED ENERGY METER (OPTIONAL) .....	17
12 - DOOR SWITCH .....	18
13 - TILT SENSOR .....	18
14 - ERROR AND MALFUNCTION CONDITIONS .....	19
14.1 - ERROR CONDITIONS .....	19
15 - CLEANING AND MAINTENANCE .....	19
16 - PERIODIC MAINTENANCE LIST .....	20
17 - WIRELESS LAN TRANSMITTER SPECIFICATIONS .....	21

## 1 - SAFETY INFORMATION



**CAUTION**  
**RISK OF ELECTRIC SHOCK**



**CAUTION:** ELECTRIC VEHICLE CHARGER DEVICE SHALL BE MOUNTED BY A LICENSED OR AN EXPERIENCED ELECTRICIAN AS PER ANY REGIONAL OR NATIONAL ELECTRIC REGULATIONS AND STANDARDS IN EFFECT.



**CAUTION**



AC grid connection and load planning of the electric vehicle charging device shall be reviewed and approved by authorities as specified by the regional or national electric regulations and standards in effect. For multiple electric vehicle charger installations the load plan shall be established accordingly. The manufacturer shall not be held liable directly or indirectly for any reason whatsoever in the event of damages and risks that are borne of errors due to AC grid supply connection or load planning.



**CAUTION: FOR DEVICES WITHOUT EMERGENCY BUTTON;**

If any suspicious or emergency situation arises at the charging station aside from normal operation, start by halting the charging process through the vehicle (using the appropriate switch or button, which may vary depending on the model), and then disconnect the socket. As an alternative option, consider switching off the MCB or RCCB in the panel where the product is energized by the installer.

**IMPORTANT - Read these instructions fully before installing or operating**

### 1.1 - SAFETY WARNINGS

- Keep this manual in a safe place. These safety and operating instructions must be kept in a safe place for future reference.
- Check that the voltage marked on the rating label and do not use charging station without appropriate mains voltage.
- Do not continue to operate the unit if you are in any doubt about it working normally, or if it is damaged in any way - switch off the mains supply circuit breakers (MCB and RCD) in upstream distribution panel. Consult your local dealer.
- The ambient temperature range during charging should be between  $-35\text{ }^{\circ}\text{C}$  and  $+50\text{ }^{\circ}\text{C}$  (without direct sunlight) and at a relative humidity of between 5 % and 95 %. Use the charging station only within these specified operating parameters.
- The device location should be best selected to avoid excessive heating of the charging station. High operating temperature caused by direct sunlight or heating sources, may cause reduction of charging current or temporary interruption of charging process.
- The charging station is intended for outdoor and indoor use. It can also be used in public places.
- To reduce the risk of fire, electric shock or product damage, do not expose this unit to severe rain, snow, electrical storm or other severe weathers. Moreover, the charging station shall not be exposed to spilled or splashed liquids.

- Do not touch end terminals, electric vehicle connector and other hazardous live parts of the charging station with sharp metallic objects.
- Avoid exposure to heat sources and place the unit away from flammable, explosive, harsh, or combustible materials, chemicals, or vapors.
- Risk of Explosion. This equipment has internal arcing or sparking parts which should not be exposed to flammable vapors. It should not be located in a recessed area or below floor level.
- To prevent risk of explosion and electric shock, ensure that the specified Circuit Breaker and RCD are connected to building grid.
- Charging Station bottom must be at (or above) the ground level.
- Adaptors or conversion adaptors are not allowed to be used. Cable extension sets are not allowed to be used.



**WARNING:** Never let people (including children) with reduced physical, sensory or mental capabilities or lack of experience and or knowledge use electrical devices unsupervised.



**CAUTION:** This vehicle charger unit is intended only for charging electric vehicles not requiring ventilation during charging.

## 1.2 - INSTRUCTIONS FOR DEALING WITH A FIRE AT CHARGING STATION

- **Personal Safety:** If you notice a fire or signs of danger, your own safety is the most important. Do not take risks.
- **Immediate Notification of Emergency Services:** Contact the appropriate emergency services in your region. Dial 998 or 112 the emergency number.
- **Discontinuing Charging:** If safe to do so, disconnect the charging cable from the vehicle and the charging station.
- **Use of Fire Extinguishing Agents:** If a fire extinguisher or other fire-fighting equipment is nearby and you are trained to use them, attempt to extinguish the fire. However, never risk your own safety.
- **Avoid Direct Contact with the Fire:** Do not attempt to extinguish the fire if you do not have the appropriate equipment or knowledge, or if the fire is too large or dangerous.
- **Move Away from the Station:** If the fire is uncontrolled or growing in strength, move away from the charging station while maintaining a safe distance.
- **Avoid Inhaling Smoke:** Try to avoid inhaling smoke. If possible, cover your nose and mouth with a damp cloth or clothing.
- **Warn Others in the Area:** Inform others in the vicinity about the fire hazard and encourage them to leave the area.
- **Wait for Emergency Services:** After safely leaving the area, wait for the arrival of emergency services at a location that is safe for you.
- **No Return to the Station Premises:** Do not return to the charging station premises until the emergency services have completed their operation.
- **Reporting the Incident:** Contact customer support to report the incident.

Remember, safety is paramount. In the event of a fire, always consult with local emergency services and follow their instructions.

### 1.3 - GROUND CONNECTION WARNINGS

- Charging station must be connected to a centrally grounded system. The ground conductor entering the charging station must be connected to the equipment grounding lug inside the charger. This should be run with circuit conductors and connected to the equipment grounding bar or lead on the charging station. Connections to the charging station are the responsibility of the installer and purchaser.
- To reduce the risk of electrical shock, connect only to properly grounded outlets.
- **WARNING** : Make sure that during installing and using, the charging station is constantly and properly grounded.

### 1.4 - POWER CABLES, PLUGS and CHARGING CABLE WARNINGS

- Be sure that plugs and sockets are compatible on charging station side.
- A damaged charging cable can cause fire or give you an electric shock. Do not use this product if the flexible Charging cable or vehicle cable is frayed, has broken insulation, or shows any other signs of damage.
- Ensure that the charge cable is well positioned thus; it will not be stepped on, tripped over, or subjected to damage or stress.
- Do not forcefully pull the charge cable or damage it with sharp objects.
- Never touch the power cable/plug or vehicle cable with wet hands as this could cause a short circuit or electric shock.
- To avoid a risk of fire or electric shock, do not use this device with an extension cable. If the mains cable or vehicle cable is damaged it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- Use appropriate protection when connecting to the main power distribution cable.

### 1.5 - REQUIRED UPSTREAM PROTECTIONS

- Class I/B Lightning Protection should be connected to the upstream distribution board. It is recommended that the cable length between the charger and the protection device be at least 10m. \*The charger is equipped with a Class II/Type C Surge Protective Device (SPD).
- To prevent the residual current, Type A residual current device should be used on the panel before the device. The minimum current sensitivity should be set to 30mA.
- Circuit Breaker device should be connected to the upstream distribution board.

Model	Power	Input Voltage	Maximum Input AC current	Recommended Minimum Neutral Conductor Cross-Section
EVC12-DC40C	40kW	400V (nom.)	62A	16mm <sup>2</sup>
		360V (-%10)	68A	

- Cable cross-sections must be selected by the installer in accordance with local and international standards, considering the specified maximum AC input current values, minimum allowed input voltage values, installation distances, and mounting location conditions.

- The PE cable cross-section must be at least 16 mm<sup>2</sup>.
- It is recommended to use a CAT6 SFTP Ethernet cable.
- Cables must be selected for outdoor use.
- Cables must be UV-protected and suitable for installation in underground conduits according in accordance with local regulations.
- The AC input cable glands supplied with the product are suitable for cables with a diameter range of 22–32 mm.

## 2 - DESCRIPTION

<b>Model Name</b>	<p><b>EVC12-DC40**</b></p> <p>1st Asterisk (*) : Rated Power                            40    : 40 kW DC Power Output</p> <p>2nd Asterisk (*) : DC output combination 1                            C     : CCS Output</p> <p>3rd Asterisk (*) : Meter Option                            Blank  : No MID meter                            -MID   : MID meter                            -EICH  : Eichrecht Meter</p>
<b>Cabinet</b>	EVC12-DC40

### 3 - ELECTRICAL SPECIFICATIONS

<b>IEC Protection class</b>		Class I
<b>Power Input</b>	<b>Input Rating</b>	230/400 Vac $\pm 10\%$ , 50/60 Hz, 62 A / 3 Phase
	<b>Connection</b>	3L - N - PE (TN-S, TN-C-S or TT)
	<b>Residual Current Monitoring</b>	230VAC RCBO 1P+N, Type A, 30mA
	<b>Power Factor</b>	> 0.98
	<b>Efficiency</b>	> % 95
<b>Output CCS</b>	<b>Max Power</b>	40 kW
	<b>Voltage Range</b>	200 – 920 V
	<b>Maximum Current</b>	133A
	<b>Interface Compliance</b>	IEC 62196-1 / 3 IEC 61851-1 / 23 / 24 ISO 15118-1 / 2 / 3 DIN 70121
<b>Internal Protections</b>		Residual current device, Insulation monitoring, Over current / Over voltage / Under voltage / Short circuit / Over Temperature / Surge Protection

### 4 - USER INTERFACE & AUTHENTICATION

<b>Display</b>	7" Color TFT LCD without Touch Screen (16:9)
<b>RFID Reader Module</b>	ISO-14443A/B and ISO-15693
<b>User Interface</b>	Illuminated buttons
<b>Payment module</b>	Optional Contactless module
<b>Plug&amp;Charge</b>	ISO15118
<b>DC MID Meter</b>	MID Meter Certified Eichrecht Conformity (Optional)

## 5 - CONNECTIVITY

<b>LAN Connectivity</b>	10/100 Mbps Ethernet
<b>WLAN Connectivity</b>	2.4GHz/5GHz: 802.11 a/b/g/n/ac
<b>Mobile Connectivity</b>	GSM 900/1800 UMTS 900/2100 LTE Band 1/3/7/8/20/28A
<b>OCPP Specification</b>	OCPP 1.6 J








## 6 - MECHANIC SPECIFICATIONS

<b>Material</b>	Sheet Metal	
<b>Protection Degree</b>	Ingress Protection Impact Protection	IP54 IK10
<b>Cooling</b>	Forced Air Cooling Fan	
<b>Cable Length</b>	CCS2: 3,5m(default) or 5m(option)	
<b>Dimensions (Product)</b>	Height:635 mm Width:630 mm Depth:250 mm	
<b>Dimensions (with packing)</b>	1000 x 850 x 560 mm (H x W x D)	
<b>Weight (Product)</b>	80kg	
<b>Weight with Package</b>	135kg	

## 7 - ENVIRONMENTAL TECHNICAL SPECIFICATIONS


<b>Operating Condition</b>	Temperature	-35 °C to + 50 °C (Derating is applied over + 40 °C to 50 °C) For products with credit card option -20 °C to + 50 °C
	Humidity	5 % - 95 % (Relative humidity, non-condensing)
	Altitude	0 - 2000m

## 8 - BEHAVIOR OF STATUS INFORMATION LED

STATUS OF LED	MODE	
	White Glowing	When the product is initialized.
	Green Illuminates Steadily	While the product is in standby. (No charge).
	Blue Illuminates Steadily	When the cable is inserted to EV.
	Charge percentage is according to the number of leds, one led blinks.	While Charging.
	Blue Illuminates Steadily	Charging is suspended or finished.
	Red Illuminates Steadily	Error.
	Blue until plug is removed.	Charging is finished.

## 9 - GENERAL INFORMATION


### 9.1 - INTRODUCTION OF THE PRODUCT COMPONENTS



*All products' images are given for representative purpose only*

## 9.2 - CCS Outlet


Unplug the charging plug to remove it from the device. Then plug it into the vehicle to start charging.



## 10 - CHARGING SCENARIOS (INCLUDES ALL SCENARIOS)

Connect the charging cable to the socket plug/pull out the charging plug from the socket plug.

In the main screen on the charging station display, you may either tap the plug you want to use or simply connect the plug to the vehicle.




### 10.1 - DC CCS Outlet

#### 10.1.1 - VEHICLE CONNECTION & CHARGING


1- Connect charging cable to move to payment screen.




**2-** Tap your RFID card or scan QR Code to start charging. (If AutoCharge is set in Webconfig and vehicle registration is available in the system, charging starts without reading the RFID card)



**3-** It may take a few seconds for charging session to start. Charging state can be seen in charging page.




#### 4- While charging, charging state can be seen in the main menu.





*All products' images are given for representative purpose only*

### 10.1.2 - STOP CHARGING

#### 1- Click "Stop Charging" to end the charging session.




**2- Scan your RFID card or scan QR Code to stop charging.**




**3- Disconnect the charging cable.**

After disconnection, you will automatically move to the main screen.





### 10.1.3 -CHARGING COMPLETED

The charging process is successfully completed.



### 10.1.4 - EMERGENCY STOP (Optional)

Please follow screen when emergency stop pressed.



## 11 - PRODUCTS WITH CERTIFIED ENERGY METER (OPTIONAL)

RFID/Autocharge and credit card (optional) authentication methods have different information on the meter display energy register at the beginning of the transaction.

RFID/Autocharge




Credit card




Date and time on site at the beginning of the transaction Total duration of the transaction


RFID/Autocharge



Credit card




Customer RFID/Autocharge ID



Customer credit card ID

Prefix of the charging station operator, followed by the first 6 digits and the last 4 digits of the credit card ID



Cable compensation, EVSE identification input and charging point ID\_Sw-Version\_Tariff (chargepointid\_Sw version\_tariff) with currency

RFID/Autocharge




Credit card




Energy register at the end of the transaction.

RFID/Autocharge




Credit card



## 12 - DOOR SWITCH

The behaviour of the door position can be monitored with 2 different conditions set as normally open or normally closed given via the terminal. When the doors are opened, the breaker can be controlled over the main panel outside the station with a control lead to be taken over the dry contact. This information is also transmitted to the service via OCPP.




## 13 - TILT SENSOR

When the product reaches the predefined tilt angle in either the forward or reverse direction, the tilt sensor detects this condition and transmits the tilt angle information via OCPP. As a result, the sockets are disabled and the message "Out of Order" is displayed on the screen. However, the product remains energized.

In such cases, the charging station operator must manually disconnect the power from the energy panel to which the product is connected.

Note: The default tilt angle is set to 30 degrees. This value can be modified via the WEB UI interface.



## 14 - ERROR AND MALFUNCTION CONDITIONS

- There are two type of errors or faults:
- **General Errors:** This fault or error effects all two outputs.
- **Charging Output Errors:** Only one socket or plug effected by this fault or error condition.

### 14.1 - ERROR CONDITIONS

Problem	Possible Causes	Recommended Solutions
Power Failure	Power outage or the grid voltage is not in specified range.	Check input circuit breakers are not tripped and input voltage range and rotation is as specified in installation guideline.
CCS output unavailable	RCBO is tripped	Check cable isolation first. Turn on RCBO. (See section "CIRCUIT BREAKER LOCATIONS FOR CHARGING OUTPUTS") Check functionality for the station output.
All outputs unavailable	General error	Please check if there is a power outage. Then, check the upstream distribution box circuit breaker. If the outputs are still unavailable please contact authorized service.

## 15 - CLEANING AND MAINTENANCE

### DANGER

- Do not clean your electric vehicle charging device while charging your vehicle.
- Do not wash the device with water.
- Do not use abrasive cloths and detergents. Microfiber cloth is recommended.

## 16 - PERIODIC MAINTENANCE LIST

	Maintenance Period (year)									
	1	2	3	4	5	6	7	8	9	10
Air filters	R	R	R	R	R	R	R	R	R	R
Plugs	I	I	I	I	I	I	I	I	I	I
Display	C	C	C	C	C	C	C	C	C	C
Distribution elements (MCB, RCBO)	T	T	T	T	T	T	T	T	T	T
AC input and relay terminals	T	T	T	T	T	T	T	T	T	T
DC relay terminals	T	T	T	T	T	T	T	T	T	T
DC output cable and terminals	T	T	T	T	T	T	T	T	T	T
Body	C	C	C	C	C	C	C	C	C	C
Grounding resistance	M	M	M	M	M	M	M	M	M	M

C : Clean

I : Inspect (check, approve, clean, tighten or replace if necessary)

M : Measure

T : Tighten

R : Review

### Air filters

Air filters should be replaced every year when going for maintenance.

### Plugs

All spark plugs should be checked when going for maintenance. If the plug is broken or cracked, it should be replaced. Furthermore, a charging test should be performed with all Plugs.

### Display

During maintenance, the screen should be checked using the physical buttons, as the screen is nontouch. All functions can be controlled through these buttons. If there is no issue with the button operations, the screen should be cleaned.

### Distribution elements (MCB, RCBO)

Distribution elements (MCB, RCBO) should be checked and tightened when going for maintenance. RCBO can be tightened with a torque of 2 Nm and MCB with 3 Nm.

### AC input and relay terminals

The AC input terminals should be checked and tightened when going for maintenance. The input cables shall be tightened to 3 Nm, and the AC contactor shall be tightened to 5 Nm.

## DC relay terminals

DC relay ends should be checked when going for maintenance. Tightening process should be performed with 10 Nm.

## DC output cable and terminals

DC output cable and terminals should be checked when going for maintenance. They should be checked for any damage. The tightening torque for busbar-to-busbar and busbar-to-lug connections shall be applied as follows: 8 Nm for M6 bolts, 20 Nm for M8 bolts, 25 Nm for M10 bolts, and 45 Nm for M12 bolts. For lug-to-energy meter connections, a tightening torque of 20 Nm is required.

## Body

The outer cabinet should be cleaned when going for maintenance.

## Grounding resistance

A mechanism for measuring with a megger should be installed when going for maintenance. After the piles are driven, the voltage between the two piles should be less than 1V.

# 17 - WIRELESS LAN TRANSMITTER SPECIFICATIONS

Frequency Ranges	Max Output Power
2400 - 2483,5 MHz (CH1 - CH13)	< 100 mW
5150 - 5250 MHz (CH36 - CH48)	< 200 mW (*)
5250 - 5350 MHz (CH52 - CH64)	< 200 mW (*)
5470 - 5725 MHz (CH100 - CH140)	< 200 mW (*)

(\*) '< 100 mW' for the Ukraine

## Country Restrictions

This Wireless LAN equipment is intended for home and office use in all EU countries, the UK and Northern Ireland (and other countries following the relevant EU and/or UK directive). The 5.15 – 5.35 GHz band is restrictions indoor operations only in in all EU countries, the UK and Northern Ireland (and other countries following the relevant EU and/or UK directive). Public use is subject to general authorisation by the respective service provider.

Country	Restriction
Russian Federation	Indoor use only
Israel	5 GHz band only for 5180 MHz-5320 MHz range

The requirements for any country may change at any time. It's recommended that user checks with local authorities for the current status of their national regulations for both 2.4 GHz and 5 GHz wireless LANs. Hereby, Vestel Mobilite SAN. VE TİC. A.Ş., declares that the radio equipment type EVC is in compliance with Directive 2014/53/EU and Radio Equipment Regulations 2017. The full text of the EU declaration of conformity is available at the following address: [doc.vosshub.com](http://doc.vosshub.com).

# VESTEL

## MOBILITY

**VESTEL MOBİLİTE SANAYİ VE TİCARET A.Ş. EGE SERBEST BÖLGE ŞUBESİ**

Zafer SB Mah. Ayfer Sok. No:22 İç Kapı No:1 Gazıemır, İzmir/ TÜRKİYE

Telefon (pbx) : 90 (232) 251 72 90 Fax : 90 (232) 251 73 13

Gazıemır V.D. : 837 001 0241

